


SKIPPER

Graphic Depth Sounder

GDS101

Operation and Installation Manual



SKIPPER Electronics AS
Enebakkveien 150
P. O. Box 151, Manglerud
0612 Oslo, Norway
www.skipper.no

Telephone: +47 23 30 22 70
Telefax: +47 23 30 22 71
E-mail: support@skipper.no
Co. reg. no: NO-965378847-MVA

Document no: **DM-G001-SB**
Rev: 1702
For sw ver 05.06.xx
Edition: 2019-12-10

Information:

Please visit our web site www.skipper.no for additional information.
Here you will find
product bulletins, software updates, instruction manuals, installation procedures etc.

Note:

**Do not run the sounder for a long time with the transducer in air.
The transducer may be damaged.**

Weitergabe sowie vervielfältigung dieser unterlage, verwertung und mitteilung ihres inhaltes nicht gestattet, soweit nicht ausdrücklich zugestanden. Zuwiderhandlungen verpflichten zu schadenersatz.

Toute communication ou reproduction de ce document, toute exploitation ou communication de ou son contenu sont interdites, sauf autorisation expresse. Tout manquement à cette règle est illicite et expose son auteur au versement de dommages et intérêts.

Copying of this document, and giving it to others and the use or communication of contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages.

Sin nuestra expresa autorización, queda terminantemente prohibida la reproducción total o parcial de este documento, así como su uso indebido y/o su exhibición o comunicación a terceros. De los infractores Se exigirá el correspondiente resarcimiento de daños y perjuicios.

Contents

| | |
|--|-----------|
| TERMINOLOGY..... | 6 |
| Units..... | 6 |
| Abbreviations..... | 6 |
| 1. INTRODUCTION..... | 7 |
| System Summary | 7 |
| Transducers | 7 |
| Operator Panel and Data Entry | 7 |
| Recorded Data Storage | 8 |
| Fig. 1.1 Main Display Unit Panel Layout..... | 8 |
| Fig. 1.2 System Diagram | 9 |
| Interfacing..... | 10 |
| Outputs..... | 10 |
| Inputs..... | 10 |
| Alarms..... | 10 |
| Options..... | 10 |
| Repeaters..... | 10 |
| External Printer | 10 |
| Fig. 1.3 GDS101 Primary Functions..... | 11 |
| 2. OPERATION | 12 |
| Parameter entry | 12 |
| Fig. 2.1 Setting and Parameter Entry Flowchart..... | 12 |
| Example of parameter entry | 13 |
| Operation Screens | 13 |
| Primary Operation Screens | 14 |
| Fig. 2.2. Screen 1, Primary Operation screen..... | 14 |
| Fig. 2.3. Screen 2, 2nd Operation screen..... | 15 |
| Fig. 2.4. Screen 3, 3rd Operation screen. | 16 |
| Secondary Operation Screens | 17 |
| Fig. 2.5. Screen 4, Calendar and clock setting. | 17 |
| Fig. 2.6. Screen 5, Language and units of measure setup..... | 18 |
| Fig. 2.7. Screen 6, Interface setup screen. | 19 |
| Fig. 2.8. Screen 7, History Memory Control Screen..... | 20 |
| Fig. 2.9. Screen 8, NMEA control screen..... | 21 |
| Fig. 2.10. Screen 9, System status screen..... | 22 |
| Fig. 2.11. Screen 10, Oscilloscope screen. | 23 |
| Fig. 2.12. Screen 11, Alarm screen..... | 24 |
| Principal Functions | 25 |
| Bottom detection..... | 25 |
| Ping to Ping filtering | 25 |
| Bottom Search Range | 25 |
| FIX RANGE | 25 |
| Autorange..... | 25 |
| Fixed Key Functions..... | 26 |
| Depth Range..... | 26 |
| Picture Speed..... | 26 |
| Screen Select..... | 26 |
| Day/Night and back light adjustment (brightness)..... | 26 |
| Soft key Functions | 27 |
| Gain..... | 27 |
| TVG..... | 27 |
| Digital indication..... | 27 |

| | |
|--|-----------|
| Frequency..... | 27 |
| Output Power | 27 |
| Draught..... | 27 |
| External Printer Operation | 28 |
| Alarm Settings..... | 29 |
| Alarm acknowledgement | 30 |
| Alarm buzzer..... | 30 |
| Power failure warning..... | 31 |
| History Memory | 31 |
| Clock and Calendar Settings | 32 |
| Simulator..... | 32 |
| Status Screen | 32 |
| Oscilloscope Screen | 32 |
| Nonvolatile Flash Parameter Memory | 32 |
| Non-wheelmark version of GDS101 | 33 |
| 3. USER MAINTENANCE | 34 |
| Transducer Maintenance | 34 |
| Operator Unit Maintenance..... | 34 |
| Typical Oscilloscope Screen (10) Contents | 37 |
| 4. INSTALLATION..... | 39 |
| Standard System Supply | 39 |
| Transducer Installation..... | 39 |
| Location..... | 39 |
| Installation Details | 39 |
| Fig. 4.1. Basic System Configuration. | 40 |
| Transducer Junction Box | 41 |
| Fig. 4.2. Transducer Junction Box. | 41 |
| Operator Unit Installation | 42 |
| Fig. 4.3. Operator Unit..... | 42 |
| 115/230 V Selection | 43 |
| EMC..... | 43 |
| Fig. 4.4. Voltage selection connectors and fuses, terminal board. | 44 |
| Fig. 4.5. History Memory Battery Jumper, I/O Board..... | 45 |
| Fig. 4.6 Function LEDs, Terminal, I/O and CPU Boards..... | 46 |
| Fig. 4.7. Main Wiring Diagram..... | 47 |
| Fig. 4.8. Input/Output Circuitry. | 48 |
| Interfacing | 49 |
| NMEA interface | 49 |
| Alarm relay..... | 49 |
| External alarm reset function | 49 |
| Fig. 4.9. NMEA connector XJ303..... | 49 |
| Log Pulse input | 50 |
| Remote Transducer Selector FEEDB (Feedback)..... | 50 |
| Transmitter trigger pulse and bottom pulse outputs..... | 50 |
| Analogue interfaces..... | 50 |
| Fig. 4.10. Data Communication Interfaces. | 51 |
| Fig. 4.11. Alarm interconnections | 52 |
| External Interface Ports..... | 53 |
| Fig. 4.12. External Interface Ports | 53 |
| Options | 54 |
| Repeaters/Slaves | 54 |
| Remote Keyboard..... | 54 |
| Remote Sounding Control..... | 54 |

| | |
|--|-----------|
| 5. START-UP AND SYSTEM ADAPTION | 55 |
| System Adaptation | 55 |
| Analogue Output and Log Pulse Input Range Selection..... | 55 |
| Language and Units of Measure | 55 |
| Remote Transducer Selector | 55 |
| Low frequency indication | 55 |
| NMEA Setup | 56 |
| NMEA transmitted/output messages..... | 56 |
| NMEA received/input messages | 57 |
| Setting of “Non-wheelmark” functions | 58 |
| Calibration, Sound Speed..... | 58 |
| External Ping Control..... | 58 |
| 6. SPECIFICATIONS, DIMENSIONS..... | 59 |
| Transducer and Junction Box..... | 61 |
| Operator Unit Cabinet..... | 61 |
| 7. SERVICE | 62 |
| CPU Board Setup Procedure..... | 63 |
| CPU PCA 6742VE..... | 63 |
| Master Reset Procedure | 64 |
| Upgrading Software | 64 |
| 8. APPENDIX, MISCELLANEOUS DRAWINGS | 65 |
| Fig. 9.1 Transducer Selector Connection | 66 |
| Fig. 9.2 Transducer Selector | 67 |
| Fig. 9.3 Cable Gland Connection..... | 68 |
| Fig. 9.4 EMC Mounting Kit..... | 69 |
| 9. WARRANTY AND UTILIZATION | 70 |
| Warranty:..... | 70 |
| Utilization: | 70 |

Terminology

Units

| | |
|---------------|---|
| Depth | Meters (m), Feet (ft), Fathoms (ftm) or Braccias (br) |
| Picture speed | min:sec / div |
| Speed | Kilometer/hour (km), miles/hour(mi/h) or Knots (kn) |
| Temperature | Degrees Celsius (°C) |

Abbreviations

In addition, the following symbols are used on the runtime screens:

| | |
|--------|---|
| kHz | KiloHertz. Frequency |
| TVG | Time variable gain |
| DBT | Depth below transducer |
| DBK | Depth below keel |
| DBS | Depth below surface |
| ALF | Alert sentence compliant to IEC62288 2014 |
| ALR | Alert sentence |
| TEMP ° | Text for TEMPerature |

In menu / setup screens, the following abbreviations are used:


| | |
|---------------|--|
| NMEA | National Marine Electronics Standard NMEA-0183 |
| LCD | Liquid-Crystal Display |
| IEC | International Electrotechnical Commission |
| IMO | International Maritime Organization |
| AC | Alternating Current |
| DC | Direct current |
| V | Voltage |
| mA | MilliAmpere |
| VGA | Video Graphic Display |
| UTC | Coordinated Universal Time |
| m | Meter |
| EMC | Electro Magnetic Compatibility |
| Draught/Draft | Draught is normally defined as the distance from surface to lowest part of hull (keel). For GDS101 draught is defined as the distance from surface to transducer. |

1. Introduction

System Summary

GDS101 is a navigation echo sounder with a large high resolution graphic LCD. The echo sounder graphics are continuously shown on the LCD along with complete navigational details.

The colour bar:



It is possible to connect an external printer to the operator unit. The sounder contains a 24 hour history memory that can be printed out. Depth, time and all available navigation data are stored continuously so that the last 24 hours of information is always available. All this information may also be printed on the external printer. All IMO requirements are met or exceeded. Comprehensive interfaces are available including IEC 61162-1:2007(E) (NMEA 0183) inputs and outputs.

Transducers

GDS101 is prepared for connection to transducers of the following frequencies: 38, 50 and 200 kHz. One or more of the transducers may be connected at the same time, and the desired transducer may be selected from the operator panel.

Operator Panel and Data Entry

The operator unit contains a graphic LCD and a keyboard with fixed keys, soft keys and a rotating encoder. The function of each soft key button depends on the active screen, and the buttons are labeled on the lower rim of the LCD. The display is backlit, and contrast and backlight intensity may be adjusted by the user. The echogram is displayed continuously on the LCD and stored in the 24 hour history memory. An optional external printer is used if hard-copy documentation is required. The operator unit is normally flush mounted. Power supply options are 115/230 V AC or 24 V DC. The power consumption is app. 70 Watt at 115/230 V AC or 50 Watt at 24 V DC.

Several screens may be selected to enter various settings and parameters. Each screen has a selection of soft key buttons. Screens 1 through 3 are primary operation screens with appropriate operator controls. Screens 4 through 11 are parameter setup and system supervision screens. The various screens will be described in detail later.

Recorded Data Storage

The measured depth and other navigational data is continuously stored in the 24 hour history memory. A standard printer HP Deskjet or Epson D88/LQ350 (all with Centronics parallel interface) may be connected for paper copy. Ask local representative or manufacturer for specifications. (Contact details on title page).

Warning!

False bottom echoes may occur when:

- The bottom is out of range.
- Extreme noise conditions are present.
- Bottom signal may be lost for other reasons, like wakes or aeration below transducer.




Fig. 1.1 Main Display Unit Panel Layout




Fig. 1.2 System Diagram

Interfacing

The GDS101 has several interface possibilities.

Outputs

- Transmitter trigger pulse and bottom pulse outputs. “Transmitter trigger pulse and bottom pulse outputs” on page 50
- Analogue output 0 - 10 V or 4 - 20 mA. See “[Analogue interfaces](#)” on page 50.
- IEC 61162-1:2007(E) (NMEA 0183). See “” on page 50.
- External alarm relay output. See “[Alarm relay](#)” on page 49.
- External printer. See “[External Interface Ports](#)” on page 53.
- External VGA monitor. See “[External Interface Ports](#)” on page 53.

Inputs

- Log input 100/200/400/20000 pulses per nautical mile. See “[Log Pulse input](#)” on page 50.
- IEC 61162-1:2007(E) (NMEA 0183) interface input of position, heading, speed and UTC. “NMEA Setup” on page 56.
- Remote control and synchronisation of transmitter. (Option). See “[External Ping Control](#)” on page 58.
- Remote transducer switch. See “[Fig. 9.2 Transducer Selector](#)” on page 67.
- Remote keyboard. See “[Remote Keyboard](#)” on page 54.
- External alarm reset. See “[External alarm reset function](#)” on page 49.

Alarms

NMEA and a potential free relay contact is provided in GDS101 for interface to external alarm systems. Shallow and deep water alarms may be selected from screen 1. See “[Fig. 2.2. Screen 1, Primary Operation screen.](#)” on page 14. Alarm settings is described in ““Alarm Settings” on page 29”.

Options

Repeaters

Digital depth slave repeaters may be connected to the system. Along with the graphic display repeaters, there may also be installed a remote keyboard.

External Printer

Printer for endless paper or ink-jet printer for single sheets may be connected for hardcopy requirements. Ask local representative or manufacturer for specifications. (Contact details on title page).

GDS101 PRIMARY FUNCTIONS




Fig. 1.3 GDS101 Primary Functions

2. Operation

When the installation is complete, and power is connected to the operator unit, the system is switched on-off by power switch(es) inside the cabinet. See “[Fig. 4.4. Voltage selection connectors and fuses, terminal board.](#)” on page 44.

Parameter entry

The fixed function and soft key buttons of the various screens along with the rotating encoder, facilitates entry of parameters, setpoints and other data. The following flowchart illustrates the procedure for changing settings and entering data. The various screens are shown in detail in the operation section.




Fig. 2.1 Setting and Parameter Entry Flowchart

Example of parameter entry

Suppose you want to enter a value of 800 m for the depth range. Press the DEPTH RANGE button several times and observe the depth range sequencing through the standard values 10, 50, 100, 500, 1000 m. Press till the range is 500 m. Then press the DEPTH RANGE button again and keep it pressed while you turn the encoder clockwise. Observe the depth range increase to 800 m, release the encoder and the DEPTH RANGE button. You could also have started from the standard value 1000 m and decreased to 800 m by turning the encoder counter-clockwise.

Operation Screens

Each of the operation screens contains a graphic picture and a selection of up to 6 soft key buttons. The various screens are selected by keeping the SCREEN SELECT button pressed and rotating the encoder in either direction. Turning the encoder clockwise cycle the screens in the sequence 1 to 11, and counter clockwise rotation cycles the screens in the sequence 11 to 1. Screens no. 1, 2 and 3, covering the primary functions, may also be cycled by repeatedly pressing the SCREEN SELECT button.

The screen layouts are outlined in fig. 2.2 through 2.12. The various soft key functions are described with each screen.

Primary Operation Screens




Fig. 2.2. Screen 1, Primary Operation screen.

This screen shows the main graphic echo gram. Left hand digital indication may be enabled from screen 2.

| Soft key | Name | Range/value | Default value | Description |
|----------|---------|-------------|---------------|--|
| 1 | GAIN | 0 - 100 % | 20 % | Gain adjustment. (100 % is max. gain). See “Gain” on page 27. |
| 2 | TVG | 0 - 100 % | 36 % | Time Variable Gain adjustment. (0 % is max suppression). Suppression of echoes from 0 - 40 meter. See “TVG” on page 27. |
| 3 | MARK | Line | | Print mark line/print screen. |
| 4 | PRINT | On/off | Off | Start and stop of continuous printing. (If printer is switched off or not connected, this button is “Dimmed”). |
| 5 | ALARM ▲ | 0 - 100 m | 0 m | Shallow water alarm adjustment. See”Alarm Settings” on page 29. |
| 6 | | | | |

The currently selected transducer (frequency) is indicated at the bottom of all screens along with optional transducer position, e.g. 200 kHz/FWD. (DRT0.00 m and 200 kHz/FWD are toggling with 1 sec. interval.) Selection of the transducer position reference is performed in screen 10. See [“Fig. 2.11. Screen 10, Oscilloscope screen.” on page 23.](#)




Fig. 2.3. Screen 2, 2nd Operation screen.

This screen shows the main graphic echo gram. Left hand digital indication may be enabled from this screen.

| Soft key | Name | Range/value | Default value | Description |
|----------|-----------|-------------------|---------------|---|
| 1 | DIGITAL | Off, small, large | Off | Control of digital depth indication. |
| 2 | FREQUENCY | 38*/50/200 kHz | 50 kHz | Transducer selection. (Have to be "installed" in screen 10, soft key 2 and 3). See " Fig. 2.11. Screen 10, Oscilloscope screen. " on page 23. |
| 3 | MARK | Line | | Print mark line/dump screen. |
| 4 | PRINT | On/off | Off | Start and stop of continuous printing. (If printer is switched off or not connected, this button is "Dimmed"). |
| 5 | | | | Not used. |
| 6 | SYSTEM | On/off | On | Switch system off. Switch on with any button. (NOTE: There is still power on the GDS101). |

* **Note:** 38 kHz may vary if other frequency options are installed.(Requires hardware change)




Fig. 2.4. Screen 3, 3rd Operation screen.

This screen shows the main graphic echo gram. Left hand digital indication may be enabled from screen 2.

| Soft key | Name | Range/value | Default value | Description |
|------------|-----------|---------------------------------|---------------|---|
| 1 | POWER | 1 - 100 % | 50 % | Transmitter power adjustment. See “Output Power” on page 27. |
| 2 | DRAUGHT | -99.99 - 99.9 m | 0.00 m | Draught correction, must be set individually for each frequency. For draught, see “Draught” on page 27. |
| 3 (Option) | SOUND | 1400 - 1550 m/s | 1500 m/s | Sound speed setting, (option). |
| 4 | AUTORANGE | On/off | Off | Autorange control. |
| 5 (Option) | PING | Continuous, edge, level, single | Continuous | Ping control, (option). See “External Ping Control” on page 58. |
| 6 | | | | |

Note: Soft keys 3, and 5 are optional functions available in “Non-wheelmark” versions of GDS101.

Secondary Operation Screens




Fig. 2.5. Screen 4, Calendar and clock setting.

This screen shows the main graphic echo gram. Left hand digital indication may be enabled from screen 2.

| Soft key | Name | Range/value | Default value | Description |
|----------|--------------|-------------|---------------|---|
| 1 | PRINTER | Manual/auto | Manual | External printer start options. Auto: Printer start, if depth alarm is activated. |
| 2 | | | | Not used. |
| 3 | Y(EA)R.MONTH | 01.03 -> | | Calendar year setting. |
| 4 | DAY | 1 - 31 | | Calendar day setting. |
| 5 | HOURS | 0 - 23 | | Real time clock hours setting. |
| 6 | MINUTES | 0 - 59 | | Real time clock minutes setting. |

Note: If GPS is connected, soft key 3, 4, 5 and 6 are controlled by GPS.




Fig. 2.6. Screen 5, Language and units of measure setup.

This screen shows the main graphic echo gram. Left hand digital indication may be enabled from screen 2.

| Soft key | Name | Range/value | Default value | Description |
|----------|------------|--|---------------|---|
| 1 | SET LOW | 10 - 250 kHz (24, 28, 30, 33, 38 kHz) | 38 kHz | Adjust indicated frequency of lower frequency channel. Note. Active only if 38 kHz is selected as transducer frequency on “Fig. 2.3. Screen 2, 2nd Operation screen.” on page 15. |
| 2 | LANGUAGE | English, French, Spanish, Russian, German, Norwegian | English | Screen language selection. |
| 3 | DEPTH | Meters, feet, fathoms, braccias | Meters | Unit of measurement for depth. |
| 4 | PICT.SPEED | Min:sec | Min:sec | Unit of measurement for picture speed. (See Note below). |
| 5 | VESSEL SPD | Knots, km/h, mi/h | Knots | Unit of measurement for vessel speed. |
| 6 | SOUND SPD | m/sec, ft/sec | m/sec | Unit of measurement for sound speed. |

Note: If a speed log is connected, on NMEA input or pulse input, it is possible to select different “PICT. SPEED” units.




Fig. 2.7. Screen 6, Interface setup screen.

This screen shows the main graphic echo gram. Left hand digital indication may be enabled from screen 2.

| Soft key | Name | Range/value | Default value | Description |
|----------|--------------------|------------------------------|---------------|--|
| 1 | PULSE | 100/200/400/20000 | 100/NM | Speed log input pulse rate. (Pulses per nautical mile). |
| 2 | ENABLE (option) | Positive/negative | Positive | Select polarity of external sync signal (remote sounding control option). |
| 3 | NMEA OUT | async (1s)/ (sync)hronous | async (1s) | Select between synchronous (with sampling rate) and asynchronous (1s period) NMEA output update. |
| 4 | | | | |
| 5 | UPPER | 0 - 199 m | 0 m | Analogue output shallow water limit = 0 V (4 mA). |
| 6 | LOWER | 1 - 200 m | 50 m | Analogue output deep water limit = 10 V (20 mA). |

Note: Soft key 2 is an optional function available in “Non-wheelmark” versions of GDS101.




Fig. 2.8. Screen 7, History Memory Control Screen.

This screen shows the main graphic echo gram. Left hand digital indication may be enabled from screen 2.

| Soft key | Name | Range/value | Default value | Description |
|----------|------------|----------------------|---------------|--|
| 1 | HISTORY | On/loop/extended/off | On | On/Off: Start/stop (keep) history recording. Loop: The oldest recordings file will be deleted when the disk is full. Extended: The recordings will stop when the disk is full. (Except for the latest 24 hours, which are always available). For more info, see “History Memory” on page 31. |
| 2 | HISTORY | Recording/playback | Recording | Record/playback of history. |
| 3 | HIST. HOUR | -23 - 0 hour | | History playback spooling, hours. (Note: Active only in playback mode). |
| 4 | HIST. MIN | -59 - 0 min | | History playback spooling, minutes. (Note: Active only in playback mode). |
| 5 | MARK | Line | | Print mark line/dump screen. |
| 6 | HIST. FRMT | Text/bin | Text | Toggle between text and binary recording format. |




Fig. 2.9. Screen 8, NMEA control screen.

This screen shows list of received or transmitted NMEA messages and half screen echogram.

| Soft key | Name | Range/value | Default value | Description |
|----------|---------|---|--|--|
| 1 | SCREEN | Print | | Print screen. |
| 2 | BAUD | 4800/9600 | 4800 | NMEA baud rate selection. |
| 3 | IN/OUT | COM 1/COM 2 | COM 1 | The text window shows received or transmitted messages on the presently selected channel (COM 1 or COM 2). See "" on page 50. |
| 4 | MESSAGE | DPT, DBS, DBT, DBK, PKSKP, CHECK SUM, EN250, EN250 D#, XDR, ALARM | DPT: On DBS: Off DBT: Off DBK: Off PKSKP: On CHECK SUM: On EN250: Off EN250 D#: Off XDR: Off ALARM: Off | Select if message should be on/off by soft key 5. Alarm may be configured as ALF or ALR in "Screen 11" CHECKSUM, set off if the nmea messages should not contain checksum. |
| 5 | STATUS | On/off | | Select if MESSAGE should have "On or "Off" status. |
| 6 | DISPLAY | Off/input/output | Input | Selects what kind of information to be displayed. Off: None. Input: Received NMEA messages. Output: Transmitted NMEA messages. |




Fig. 2.10. Screen 9, System status screen.

This screen shows a comprehensive list of system settings and parameters

| Soft key | Name | Range/value | Default value | Description |
|----------|-----------|--|---------------|--|
| 1 | SCREEN | Print | | Print screen. |
| 2 | PRINTER | HP DeskJet/Epson-350 (LQ300+) /Epson-D88/Built-in printer. | Epson-D88 | Select type of printer that is connected. |
| 3 | FIX RANGE | On/off | On | Limit search range to window. FIX RANGE “on” gives better detection in case of noisy signal. |
| 4 | | | | |
| 5 | VESSEL | Merchant 1, merchant 2, navy 1, navy 2 | Merchant 1 | Upper right screen icon selection. |
| 6 | SIMULATE | On/off | Off | Built-in simulator control. See “Clock and Calendar Settings” on page 32. |




Fig. 2.11. Screen 10, Oscilloscope screen.

This screen shows receiver output versus time and half screen echo-gram.

| Soft key | Name | Range/value | Default value | Description |
|----------|------------|--|---------------|--|
| 1 | SCREEN | Print | | Print screen. |
| 2 | TRANSDUCER | 38, 50, 200 kHz | 50 kHz | Transducer selection for soft key 3. |
| 3 | LOCATION | Pos? Not installed, FWD, AFT, PORT, STRB, FWD/AFT, PORT/STRB, | Pos? | If "not installed" is selected for one of the frequencies, it will not be available in screen 2, soft key 2. 2 transducers with transducer selector (ENS518): See " Fig. 9.1 Transducer Selector Connection " on page 66 and " Remote Transducer Selector FEEDB (Feedback) " on page 50. |
| 4 | GAIN | 0 - 100 % | 20 % | Gain adjustment. See " Gain " on page 27. |
| 5 | TVG | 0 - 100 % | 36 % | Time Variable Gain adjustment. See " TVG " on page 27. |
| 6 | POWER | 1 - 100 % | 50 % | Transmitter power adjustment. See " Output Power " on page 27. |




Fig. 2.12. Screen 11, Alarm screen.

This screen shows the main graphic echo gram.

| Soft key | Name | Range/value | Default value | Description |
|----------|-------------------------------|-----------------|---------------|---|
| 1 | AL RST | ALF/ALR A/ALR B | ALF | Definition of Alarm sentence as ALF or ALR and how to react when receiving external acknowledge |
| 2 | | | | |
| 3 | ALARM ▲ ID (Shallow alarm) | 0-999 | 230 | Can only be changed in ALR(A) or ALR(B) NMEA alarm Id for "Shallow water alarm" |
| 4 | | | | |
| 5 | | | | |
| 6 | AUDIO ALR | ON/OFF | ON | In ALF allways on. May be switched off in ALR(A) or ALR(B) |

Principal Functions

Bottom detection

GDS101 employ a bottom detection algorithm that will try to extract the bottom signal from all kinds of noise and secondary echoes. When GDS101 is tracking the bottom normally, a thick black line is shown, and below that, a ribbon with a hatched pattern. This pattern has two levels of hatching. The darkest represent strong and unambiguous bottom echoes. The lighter hatching represents weaker signals possibly occasional detection misses. If the software can detect no bottom for several pings, the hatched ribbon disappears.

During normal bottom tracking, a digital value is shown by the bottom contour at the right side of the screen. If the software algorithm loses track of the bottom altogether, a warning beep is heard and the black line and hatching band disappears. A warning message: “Lost bottom” is shown in the screen’s lower right corner.

Ping to Ping filtering

Part of the bottom detection algorithm is the ping to ping filtering. The next bottom is searched for in a time and strength window based on the strength and timing of the previous bottom echoes. This procedure reduces the probability of tracking schools of fish or secondary echoes as bottom. If no bottom is detected in the calculated window, the window is gradually increased in size until the full time and strength window is used.

Bottom Search Range

FIX RANGE

This function is used to control the search range for the bottom detection algorithm. See [“Fig. 2.10. Screen 9, System status screen.” on page 22.](#)

When this function is on, bottom is only searched for within the selected display range.

When the function is off, bottom is searched for within the entire functional range of the echo sounder.

Autorange

The Autorange will automatically adjust the depth range to maintain the bottom contour within the middle half of the screen. See [“Fig. 2.4. Screen 3, 3rd Operation screen.” on page 16.](#)

When the optional printer is started, auto range is automatically disabled, and the present depth range is selected as fixed.

The default settings are “FIX RANGE ON” and “AUTORANGE OFF”. This will give less noise on screen in case of weak signal.

Fixed Key Functions

Depth Range

The DEPTH RANGE button can be used to set the depth limit between 10 and 1600 m. Standard values available by repeatedly pressing the button are 10, 50, 100, 500 and 1000 m.

Picture Speed


Picture speed may be referred to either time or vessel speed. If no speed log is connected, picture speed will always be referred to time, (“min:sec/div”). Time referenced picture speed may be selected between 20 seconds per division and 5 minutes per division. Vessel speed referenced picture speed may be selected between 0.04 and 5 nautical miles per division. If a speed log is connected, it is possible to select different “PICT.SPEED” units in screen 5. The ping-rate range depends on the depth range, and the fastest ping rate at shallow depths is about 5 pings per second.

Screen Select

The SCREEN SELECT button facilitates selection of one of the 10 screen and soft key layouts. The 3 primary operation screens may be cycled by repeatedly pressing the SCREEN SELECT button. Access to the remaining screens is through encoder operation. The screens are cycled in an endless, bidirectional loop, e.g. turning the encoder counter-clockwise, will activate screen 10 after screen 1. Turning the encoder with no buttons pressed always force screen 1.

Day/Night and back light adjustment (brightness)

Day/Night vision may be selected by pressing this button. These two modes differs by colour presentation, which are optimized for different ambient light conditions.



Soft key Functions

Gain

The received signal gain may be adjusted from 0 to 100 % to allow for optimal echo levels from bottom and other objects. The gain setting affects signals from all depths. See “[Fig. 2.2. Screen 1, Primary Operation screen.](#)” on page 14 and “[Fig. 2.11. Screen 10, Oscilloscope screen.](#)” on page 23.

TVG

Time Variable Gain may be adjusted from 0 to 100 % to allow for detailed echo control from the 0 - 50 m depth range. A low setting will reduce the gain in the area near the surface to suppress noise and unwanted echoes from this area. See “[Fig. 2.2. Screen 1, Primary Operation screen.](#)” on page 14 and “[Fig. 2.11. Screen 10, Oscilloscope screen.](#)” on page 23.

Digital indication

On the operation screens, two sizes of large digital depth indicators may be selected from “[Fig. 2.3. Screen 2, 2nd Operation screen.](#)” on page 15.

1. “Small” digits.
2. “Large” digits.

Frequency

The frequency selector toggles among 38*, 50 and 200 kHz. See “[Fig. 2.3. Screen 2, 2nd Operation screen.](#)” on page 15. * Some units may have been adjusted to other frequencies.

Output Power


Power may be adjusted from 1 to 100 % in case of difficult shallow water conditions. Too high power in such cases will possibly saturate the receiver or cause detection of unwanted secondary bottom or surface echoes. See “[Fig. 2.4. Screen 3, 3rd Operation screen.](#)” on page 16 and “[Fig. 2.10. Screen 9, System status screen.](#)” on page 22. **Note:** Power capability is transducer dependant.

Draught

Draught is used to correct the Depth Below Transducer (DBT) to Depth Below Keel (DBK) or to Depth Below Surface (DBS). This is used when the transducer is not at same position as the lower part of the keel/bottom, or if ship want to know the real water depth from surface. Draught may be compensated to allow real depth from surface to be shown on the screen and printout. Negative draught values may be entered to compensate for transducers fitted above the keel. This setting also affects the NMEA transmitted values. Draught value is indicated on the lower part of the screen by a flashing/alternating number. See “[Fig. 2.4. Screen 3, 3rd Operation screen.](#)” on page 16. In addition, the floating depth on the right side of the screen now also says DBS, DBT or DBK depending on the draught value.

Note: Be aware that if you have two transducers with the same frequency and use the ENS518 transducer selector, the draught setting value will apply for both transducers.

| Draught setting | Right side additional screen tekst |
|-----------------------|------------------------------------|
| Draught = 0 (Default) | DBT |
| Draught > 0 | DBS |
| Draught < 0 | DBK |



External Printer Operation

The optional external printer is started and stopped by the PRINT button in screen 1 and 2. The printer may be used for continuous printing over a period of time or the current screen contents may be dumped to the printer for reference if something interesting is observed.

- The PRINT button switches continuous printing on and off.
- The MARK button(s) will write a line mark on the paper if it is pressed whenever the printer is running.
- If the MARK button is pressed when the printer is online, this will initiate a screen dump of the present screen contents. If printer is switched off, or not connected, the PRINT button is “dimmed”.

System (Power) On/Off


During normal daily operation, the system may be switched off from screen 2. See “[Fig. 2.3. Screen 2, 2nd Operation screen.](#)” on page 15. This operation does not disconnect the system from the power supply, but all power consuming components are switched off. The system may be switched on again by pressing any button.

Alarm Settings

The GDS101 alarm includes shallow water alarm

An alarm system may be connected to the GDS101 by NMEA com port and/or the relay contacts.


There are 3 available alarm definitions ALF, ALR(A) and ALR(B) set in “Screen 11”



The default is ALF which is compliant with IEC62288 2014.

Shallow water alarm.

Shallow water settings are performed from screen 1. Alarm limits are referred to the indicated depth.



A shallow alarm may automatically start the optional printer, if this function is enabled on screen 4.

NMEA ALF sentence

Active Alert :

SDALF,1,1,0,102103.00,A,A,V,,230,1,<1-99>,0,Shallow alarm*hh

3 beeps every 7-10 seconds, Alert text on screen ‘flashing red’

SDALC,01,01,00,0,,230,1,<1-99>

Active Alert - silenced:

SDALF,1,1,0,102103.00,A,A,S,,230,1,<1-99>,0,Shallow alarm*hh

Internal buzzer silenced for 30 seconds, Alert text on screen ‘flashing red’

SDALC,01,01,00,0,,230,1,<1-99>

Reply after local acknowledge:

SDALF,1,1,0,102103.00,A,A,A,,230,1,<1-99>,0,Shallow alarm*hh

no beep <1-99> counts for each new occurrence of the alarm , Alert text on screen ‘constant red’

SDALC,01,01,00,0,,230,1,<1-99>

Out of Active state unacknowledged: :

SDALF,1,1,0,102103.00,A,A,U,,230,1,<1-99>,0,Shallow alarm*hh

Alert text on screen ‘flashing red’

SDALC,01,01,00,0,,230,1,<1-99>

Out of Active state acknowledged (normal): :

SDALF,1,1,0,102103.00,A,A,N,,230,1,<1-99>,0,Shallow alarm*hh

Alert text on screen ‘black or disappear’

SDALC,01,01,00,0,,,<1-99>

Responsibility transfer is not accepted.

Illegal sentences will not receive a response (ARC)

Alarm acknowledgement

ALF and ALR(A): The IEC62288 2014 requires local acknowledgement of alarm. Local acknowledgement is performed by pressing any active button on the echo sounder.

ALR(B) will accept local acknowledgement and external acknowledgement by receiving the __ACK,230*hh or by operating a remote button that shorts the KEYB+ and KEYB- lines on the terminal board, (KEYB+ = J100 pin 10, KEYB- = J100 pin 11.)

Alarm buzzer

The GDS101 is equipped with an internal (local) buzzer. .

ALF: In ALF the buzzer is always on. When the alarm buzzer is active it may be silenced for 30 seconds by receiving __ACN,102104.00,,230,,A,C*hh

In ALR the local alarm buzzer may be enabled/disabled from screen 11 (AUDIO ALR). Default is enabled.

ALR(A):

When ALR(A) is set:

- Default 0 m = disabled (No shallow alarm functionality, no shallow alarm NMEA message out).
- To enable shallow alarm: Set shallow alarm to >0 m.
- “Shallow water” alarm acknowledgement only by local acknowledgement.
- External acknowledgement of “Shallow water” alarm will only silence the local buzzer.

| Power | Alarm State | ALR | Acknowledge | Alarm Relay | Local buzzer |
|-------|----------------------|-----|-------------|-------------|--------------|
| Off | | | | Not active | Not active |
| On | No alarm | V | A | Active | Not active |
| On | Alarm | A | V | Active | Active |
| On | External acknowledge | A | V | Active | Not active |
| On | Local acknowledge | A | A | Active | Not active |
| On | End of alarm | V | A | Active | Not active |

Alarm relay active: NO (normally open) = Open, NC (normally closed) = closed
 Alarm relay not active: NO = closed, NC = open

ALR(B):

When ALR(B) is set,

- “Shallow water” alarm may be acknowledged by local or external acknowledgement.

| Power | Alarm State | ALR | Acknowledge | Alarm Relay | Local buzzer |
|-------|----------------------|-----|-------------|-------------|--------------|
| Off | | | | Not active | Not active |
| On | No alarm | V | A | Active | Not active |
| On | Alarm | A | V | Not active | Active |
| On | External acknowledge | A | A | Active | Not active |
| On | Local acknowledge | A | A | Active | Not active |
| On | End of alarm | V | A | Active | Not active |

Alarm ID

Alarm identifier, used in NMEA alarm sentences to be recognized by the listener and allowing the system to uniquely identify each alarm type.

ALF, ALR(A) and ALR(B): Shallow water alarm default Id: 230

ALF: The Id is not possible to change.

ALR(A) and ALR(B): The Id may be set in screen 11.

Power failure warning

The alarm relay have 2 possible functionalities:

ALF and ALR(A): The relay will engage at power on and operate as a “power failure” warning

ALR(B): The relay will engage at power on and operate as a Shallow water alarm.

History Memory

GDS101 has a 24 hour history memory. Depth, time and all available navigation data are stored continuously, so that the last 24 hours of information is always available. The history memory is controlled from screen 7. See [“Fig. 2.8. Screen 7, History Memory Control Screen.” on page 20](#). The normal history modes are “on” and “recording”. New depth information is continuously stored in the memory while the oldest samples are discarded. Only depth information is stored along with time and whatever navigational information is available in the GDS101 (position, speed, heading). By switching HISTORY off, the stored 24 hours will be kept in the memory and no new samples will be recorded. As a warning that the memory is not recording, “HISTORY off” is flashing at the bottom of the screen. History modes “on” and “playback” will start playing the contents of the history memory on the screen and on the optional printer, if it is running. As a warning that the displayed bottom contour is from the memory and not real time, “HISTORY” is flashing at the bottom of the screen. The HIST HOURS and HIST MINUTES buttons used with the encoder, will enable positioning within the 24 hour memory to observe the desired part of the time frame during playback.

An option is available for logging of depth, settings, and some external data if applied. To activate this function, the HISTORY button must be on one of the following two settings:

Loop: In case of “loop” mode the oldest recordings file will be deleted, when the disk is full.

Extended: In case of “extended” mode, the recordings will stop, when the disk is full.

Note: If installed, (default and recommended) history data will be recorded on the external Compact Flash. On screen 9 (System status screen), this is indicated as “History disk: **Extrn**”. If the external Compact Flash is **not** installed, the history data will be recorded on the “program” Compact Flash located on the rear side of the CPU board. On screen 9 (System status screen), this indicates as “History disk: **Sys**”. See [“Fig. 2.10. Screen 9, System status screen.” on page 22](#).

Note: Always turn off the unit with the switch on the Terminal board when removing/replacing the CF disk.

TXT/BIN: A new file will be created every hour. The filename format is YYMMDDHH.[ext], where YY is current year, MM – current month, DD – current date and HH – current hour. The extension depends on the recordings type. In case of text recordings, the extension is “txt”, in case of binary format – “bin”. If the file, corresponding to the current date/time already exists, the new history will be appended; otherwise the new file will be created.

The GDS logging function, logs all changes in results or settings when the value changes. The files will be very small if the vessel sails without external inputs. However assuming all parameters are changed for every ping (impossible) and GPS is also logged, data in .txt format will give a minimum of 177 days data per GB disk space. In reality a GB can easily give a year of data.

The standard disk is 128 MB giving a minimum of 20 days, in practice 2 months. The system can be made to loop or log until the disk is full. The amount of disk left is shown on the status screen. Bin files store the same data in binary format and will be smaller. New files are started every hour, and named by the date and time. Each new file will have the full settings in the first lines.

Clock and Calendar Settings

Manual clock and calendar adjustments are carried out in screen 4. If a satellite navigator giving UTC messages is connected to the NMEA input, the clock and calendar will be automatically updated and manual adjustment is not required. See [“Fig. 2.5. Screen 4, Calendar and clock setting.” on page 17.](#)

Simulator

The GDS101 contains a built in simulator to test the screen and various interface signals. The simulator may be switched on and off on screen 9. When the simulator is operating, “DEMO” is flashing at the bottom of the screen. See [“Fig. 2.10. Screen 9, System status screen.” on page 22.](#)

Status Screen

The status screen, screen 9 shows a list of various system parameters useful for documenting system setup and operating status. The contents of this screen will be valuable information in situations where manufacturer support is required. See [“Fig. 2.10. Screen 9, System status screen.” on page 22.](#)

Oscilloscope Screen

The oscilloscope screen, screen 10 is useful when monitoring transceiver performance. The oscillogram shows the signal returned from the transceiver plotted against time and will enable service personnel to evaluate system performance and facilitate any troubleshooting. See [“Fig. 2.11. Screen 10, Oscilloscope screen.” on page 23.](#)

Nonvolatile Flash Parameter Memory

The system contains internal flash memory to maintain installation and user parameters like language and unit of measurement selection, contrast and backlight settings, etc. These parameters are automatically restored on power up. If the user parameters have never been set, default values are used.

Non-wheelmark version of GDS101

A “Non-wheelmark” version of GDS101 is available with the additional software functions available:

Remote Sounding Control

This option lets the GDS101 being controlled remotely in synchronized (edge), burst (level) or single ping modes. If installed, this option is accessible on screen 3. See [“Fig. 2.4. Screen 3, 3rd Operation screen.” on page 16.](#)

Sound Speed Calibration

This option will enable adjustment of the sound speed value used for the depth calculations. The standard value is 1500 m/s, but the user may set values from 1400 to 1550 m/s to accommodate accurate propagation speed in known water conditions. If installed, this option is accessible on screen 3. See [“Fig. 2.4. Screen 3, 3rd Operation screen.” on page 16.](#)

3. User Maintenance

Transducer Maintenance

The transducers are virtually maintenance free, but occasional cleaning may be necessary depending on sea water conditions.

Operator Unit Maintenance

The operator unit contains no user serviceable parts, and requires no maintenance apart from occasional cleaning of the front panel. Please use a soft cloth and no chemicals except cleaning alcohol.

Note: In normal usage, the system should show satisfactory results with the following settings:

- Gain = 20 %.
- TVG = 36 %.


Always try to return to these settings before continuing.

Please also try a “Master Reset”, see “[Master Reset Procedure](#)” on page <?> for more details.

Trouble Shooting

| Symptom | Cause | Remedy |
|---|--|--|
| Basic System Integrity | | |
| <ul style="list-style-type: none"> • No picture on LCD screen. | <ol style="list-style-type: none"> 1. No AC or DC power to the system. 2. System is in standby. 3. Too low screen backlight. 4. Defective LCD module or interface. 5. Voltage(s) out of range. 6. System rebooted too quickly. | <ol style="list-style-type: none"> 1. Check switches and fuses on the terminal board inside the GDS101 cabinet. 2. Press any button on panel. 3. Increase backlight setting, change to day vision. 4. Replace module or backlight inverter PCB. 5. Replace terminal PCB. 6. Turn off power switch(es) - wait a few sec, restart. |
| <ul style="list-style-type: none"> • Picture is difficult to read. | <ol style="list-style-type: none"> 1. Backlight is too weak. 2. Night vision is on during day time. | <ol style="list-style-type: none"> 1. Increase backlight setting. 2. Increase backlight setting, or change to day vision. |
| <ul style="list-style-type: none"> • Display backlight malfunctions. • Display picture is hardly visible. | <ol style="list-style-type: none"> 1. Defective backlight tubes. 2. Defective keyboard. 3. Defective backlight inverter. | <ol style="list-style-type: none"> 1. Replace tube assembly. 2. Replace keyboard PCB. 3. Replace backlight inverter PCB. |
| <ul style="list-style-type: none"> • Rotary encoder malfunctions. | <ol style="list-style-type: none"> 1. Defective encoder or interface. 2. Cabling error. | <ol style="list-style-type: none"> 1. Replace keyboard PCB or terminal PCB. 2. Check cabling to IO board J101 at both ends. (No cable on J103). |
| <ul style="list-style-type: none"> • Panel buttons malfunctions. | <ol style="list-style-type: none"> 1. Defective buttons or interface. 2. One button stuck. | <ol style="list-style-type: none"> 1. Replace keyboard PCB or terminal PCB. 2. Check key switches or replace keyboard PCB. |

Typical Status Screen (9) Contents



The status screen (9) contains information that will facilitate analysis and correction of several problems. A printout or picture of the status and oscilloscope screens should be sent by fax/E-mail with any report about functional disturbance. This will greatly facilitate remote failure analysis.

If it at all is possible to cycle through the screens and observe this information, several assumptions may be made regarding operation of the GDS101 system. Although some of the subsystems necessary for this basic system operation may still suffer from minor or intermittent operation disorders, the fact that it is possible to select and observe this screen, indicates correct operation of the following GDS101 subsystems:

- The CPU board is operating.
- The keyboard is working.
- The keyboard interface part of the I/O board is working.
- The power supplies on the terminal board are basically working.

Note: XCVR is linked to Power max (100 % = 42 - 48 V, 50 % = 23 - 27 V etc.). If the numbers are different, adjust your unit to the correct values and check if fault still occurs.


Remaining disk size diagnostics

The remaining size of the external Compact Flash is indicated at screen 9 (status), "Disk avail". The indication is in percent to the total size. If the external Compact Flash is not installed, the remaining size of the internal Compact Flash is indicated. See "[Fig. 2.10. Screen 9, System status screen.](#)" on page 22.

| Symptom | Cause | Remedy |
|--|---|--|
| Screen 9 diagnosis | | |
| Main voltages out of range <ul style="list-style-type: none"> • + 5 V: \triangleleft 4.50 - 5.00 V • + 12 V: \triangleleft 11.00 - 12.00 V • Inv 12 V: \triangleleft 11.00 - 12.00 V | <ul style="list-style-type: none"> • Defective power supply. • Power supply overload. | <ul style="list-style-type: none"> • Replace terminal board. • +5 V: Computer or I/O board problem. • +12 V: Transceiver problem. |
| <ul style="list-style-type: none"> • Lost bottom, transceiver (XCVR) voltage low. | <ul style="list-style-type: none"> • Power setting too low. | <ul style="list-style-type: none"> • Increase power setting. |
| <ul style="list-style-type: none"> • Lost bottom, transceiver (XCVR) voltage <10 V when power is 50 % or 100 %. | <ul style="list-style-type: none"> • Defective I/O card. | <ul style="list-style-type: none"> • Replace I/O card, possibly terminal board. |
| <ul style="list-style-type: none"> • System reboots intermittently. | <ul style="list-style-type: none"> • Bus cable or motherboard error. | <ul style="list-style-type: none"> • Temporary fix maybe to clean and reseal the motherboard connectors. • Replace cable and/or card. |

The other information on the status screen is a collection of information which may be observed and manipulated with the various screen soft key selections. As a reference, it will often be more convenient to observe the various settings together on this screen than to cycle from screen to screen to check on the soft key texts.

Typical Oscilloscope Screen (10) Contents



This oscilloscope screen 10 shows a typical oscillogram of a bottom echo (the tall peak in the centre of the diagram) and a weaker fish echo to the left of it. The horizontal axis represent time for the sound to travel down and back from an object. The vessel is located at the left edge of the grid, and the right edge represent the depth range. The vertical axis represent the magnitude of the echo signal received.

The length of the ping and the delay between pings, will adjust between preset limits (ping (10 m) and ping (500 m)). The actual length of these extremes are shown here.

| Symptom | Cause | Remedy |
|---|---|---|
| Basic Functionality | | |
| <ul style="list-style-type: none"> No bottom detection or bottom contour. | <ul style="list-style-type: none"> Too low gain setting. Too low TVG setting. Too low power setting. Wrong frequency selection. | <ul style="list-style-type: none"> Adjust settings. Select correct frequency. |
| <ul style="list-style-type: none"> Bottom tracking is intermittent or erroneous. | <ul style="list-style-type: none"> Marginal gain, TVG or power settings. Weather conditions. Transducer installation faulty. | <ul style="list-style-type: none"> Adjust settings. Try adjust gain, TVG or power settings. Check transducer wiring, receiver LED LD300 on IO board, or oscilloscope screen. |
| <ul style="list-style-type: none"> Bottom tracking is masked by high noise levels. | <ul style="list-style-type: none"> Too high gain setting. Too high TVG setting. Too high power setting. | <ul style="list-style-type: none"> Adjust settings. |
| | | |
| Symptom | Cause | Remedy |
| NMEA Interface etc. | | |
| <ul style="list-style-type: none"> NMEA input signals are not listed in the NMEA screen. | <ul style="list-style-type: none"> Wrong polarity input signals. | <ul style="list-style-type: none"> Swap NMEA 0183 input wires. |
| <ul style="list-style-type: none"> NMEA input signals are listed in the NMEA screen, but not accepted by the GDS101. | <ul style="list-style-type: none"> GDS101 initialization. Irregular message mnemonic. | <ul style="list-style-type: none"> Cycle GDS101 power after NMEA connection is established. |
| <ul style="list-style-type: none"> NMEA signals are not accepted by the remote system. | <ul style="list-style-type: none"> Remote (listener) setup. | <ul style="list-style-type: none"> Verify correct remote (listener) setup. |
| <ul style="list-style-type: none"> Analogue output malfunctions. | <ul style="list-style-type: none"> Incorrect range setting. | <ul style="list-style-type: none"> Verify upper and lower limits in screen 6. |
| <ul style="list-style-type: none"> Pulse output malfunctions. | <ul style="list-style-type: none"> Incorrect pulse frequency setting. | <ul style="list-style-type: none"> Verify pulse settings in screen 6. |
| <ul style="list-style-type: none"> External control inputs malfunction, inhibit/external printer control. | <ul style="list-style-type: none"> Incorrect polarity or function settings. | <ul style="list-style-type: none"> Verify settings in screen 6. |

4. Installation

Standard System Supply

A basic GDS101 system consists of the following units:


(See [“Fig. 4.1. Basic System Configuration.”](#) on page 40).

- Operator unit with installation material.
- Transducer junction box(es). See [“Fig. 4.2. Transducer Junction Box.”](#) on page 41.
- Approved transducer steel tank(s) or sea valve(s).
- Transducer(s) and mounting.
- Operation and installation manual.

Transducer Installation

Location

- A transducer should be installed in an area securing optimal measurement free from noise and aeration.
- Transducers are normally installed in the noise free area in the foreship (see A on fig.)




Optimal system operation is achieved by fitting the transducer as deep as possible on the hull. The transmitting surface of the transducer must be installed horizontally.

Do not mount transducers close to the propeller or aft of other hull installations (outlets, vents or other protruding details). It is necessary to select a part of the hull that is submerged under all load and speed conditions, and to avoid positions where air is trapped in heavy weather.

If a flat, horizontal section is not available for transducer fitting, the shipyard must construct a suitable bed.

Larger vessels are often fitted with two transducers, one fore and one aft (see fig.)



The fore transducer is the primary transducer, (normally 50 kHz). The aft transducer is a secondary transducer, (normally 200 kHz).

The aft transducer will be troubled with aeration and noise and will not operate in speed >4-5 knots. It is used to measure aft depth in shallow water.

Installation Details

Refer to SKIPPER's installation procedures in the appendix and on our web site www.skipper.no regarding information about sea valve, tank installation, welding, cable glands etc.

Note:

- Protect the active element of the transducer and **do not paint the surface**.
- Transmission in **the air must be avoided!** This may cause mechanical damage of the element.




Fig. 4.1. Basic System Configuration.

Transducer Junction Box

The standard cable fitted on the transducer is 25 m or 40 m and may be shortened. The junction box is used to interconnect the transducers fixed cable to a yard supply extension cable if the total required cable length is longer than the standard cable. In tank installations, it is required to run the standard cable in a steel protecting pipe from the tank to the highest water level. Special requirements apply in areas with explosive conditions. The junction box must always be mounted outside such areas.

Interconnect the transducer pair and its screen in the junction box, **but do not ground the screen here.**




Fig. 4.2. Transducer Junction Box.

Operator Unit Installation




Fig. 4.3. Operator Unit.

Select a position to provide free view of the panel as well as easy access during operation and service. The operator unit may be mounted flush (optional brackets are needed) in a panel, desktop mounted or directly mounted onto a bulkhead. Fig. 4.3 shows the operator unit along with the main installation dimensions. If the unit is to be flush mounted, the shown cut-out and recession depth dimensions must be observed. For details, see "[Fig. 4.3. Operator Unit.](#)" on page 42.

Remember to leave room in front of the unit to open the door a full 90 degrees.

Do not perform installation work with system power applied!!

Cables are led through the appropriate cable glands as follows:

- The cable from the transducer(s) should normally occupy the left gland.
- The right gland is used for power supply connection.
- The centre ones are used for any interface signals connected.

Power supply may be either 115/230 V AC or 24 V DC. Power consumption is app. 50 W at 24 V, app. 70W at 115/230 V.

The transducer is always connected with 1 pair plus screen. See "[Note: In the latest GDS101 versions, \(starting from Sw 5.05.02\) CMOS memory for storing "history" is not used. Here all values are stored on the Compact Flash. The jumper JP101 and battery BT100 is present only for backward compatibility.](#)" on page 45.

115/230 V Selection

If the AC power system is 115 V, GDS101 may be prepared for 115 V AC by re-connecting the connectors J102, J103 as shown in "[Fig. 4.4. Voltage selection connectors and fuses, terminal board.](#)" on page 44.

This diagram also shows position of fuses for 115/230 V AC and 24 V DC. These fuses are normal 5 x 20 mm glass fuses.


| | | | | |
|-------------------|--------------|-------|--------|------------|
| AC supply: | FS100, FS101 | 230 V | 0.5 A | slow blow. |
| | | 115 V | 1 A | slow blow. |
| DC supply: | FS102 | 24 V | 3.15 A | slow blow. |

When the installation is complete, and power is connected to the operator unit, the appropriate power switch by the power terminals is switched on. For daily operation, these switches may stay on and the unit is switched off by pressing the "SYSTEM off" button on "[Fig. 2.3. Screen 2, 2nd Operation screen.](#)" on page 15. The unit is switched on by pressing any button.

Both 115/230 V AC and 24 V DC power may be connected and switched on at the same time. If one of these supplies shuts down, changeover is automatic.

EMC

Important note: To meet the stringent EMC requirements for this type of equipment, two ferrite filters are supplied with the display unit. The transducer wires should be looped two times through these as shown in "[Fig. 9.4 EMC Mounting Kit](#)" on page 69.



AC Voltage selection:

- Transformer primary to:
- J102 for 230 V
 - J103 for 115 V

Fuses:

- **230 V AC:** FS100, FS101: 0.5 A
- **115 V AC:** FS100, FS101: 1 A
- **24 V DC:** FS102: 3.15 A

For protection, fit dummy plug on opposite connector

Fig. 4.4. Voltage selection connectors and fuses, terminal board.

History memory battery, JP101



NOTE:

JP101 is marked J103 on some boards.






Fig. 4.5. History Memory Battery Jumper, I/O Board.


Note: In the latest GDS101 versions, (starting from Sw 5.05.02) CMOS memory for storing “history” is not used. Here all values are stored on the Compact Flash. The jumper JP101 and battery BT100 is present only for backward compatibility.



LD300 on IO board



LD400 - LD403 on terminal board



LED1 on CPU board

| Power indication and function LEDs | | |
|---|-----------------------|--------|
| Terminal board | | |
| LED | Indicating | Colour |
| LD400 | + 5 V | Green |
| LD401 | + 12 V | Yellow |
| LD402 | + 12 V | Yellow |
| LD403 | + 48 V | Yellow |
| I/O board | | |
| LED | Indicating | Colour |
| LD300 | Transceiver operation | Green |
| CPU board | | |
| LED | Indicating | Colour |
| LED1 | CPU Power | Green |

Fig. 4.6 Function LEDs, Terminal, I/O and CPU Boards.




Fig. 4.7. Main Wiring Diagram.




Fig. 4.8. Input/Output Circuitry.

Interfacing

NMEA interface


The NMEA outputs provides IEC 61162-1:2007(E) (NMEA 0183) format depth information to other equipment with NMEA 0183 inputs. Baud rate is 4800 or 9600, 8 bit, no parity. Several messages may be selected in “Screen 8” and the enabled messages are transmitted every second. The NMEA inputs accept position, speed, alarm acknowledge, heading and UTC time messages from various navigators, compasses or speed logs. The two inputs provided may be connected to different talkers, and both data streams will be received. There are two outputs (both from COM 1) that will drive each minimum of 10 standard NMEA 0183 inputs.

Note: Screen 8 NMEA control screen shows in the text window received or transmitted messages on the presently selected channel (COM 1 or COM 2).

The NMEA 0183 outputs and inputs are available on the XJ303 9 Pin connector according to [“Fig. 4.9. NMEA connector XJ303.” on page 49](#), [“Fig. 4.10. Data Communication Interfaces.” on page 51](#) and [“Fig. 4.12. External Interface Ports” on page 53](#).

9 Pin D-SUB (female connector) in cabinet front seen from outside.

- **COM 1:** Pin 1-2 (RCV1 A, B), Pin 4-5 (XMT1 A, B) and 8-9 (XMT2 A, B)
- **COM 2:** Pin 6-7 (RCV2 A, B)



NMEA IN: Pin 1-2, RCV1 A, B
 NMEA IN: Pin 6-7, RCV2 A, B
 NMEA OUT: Pin 4-5, XMT1 A, B
 NMEA OUT: Pin 8-9, XMT2 A, B

Fig. 4.9. NMEA connector XJ303.

Alarm relay

An alarm relay is provided for interconnection to external alarm systems when alarm status is ALR(B) in Screen 11. This relay is normally energised, and is released by Shallow alarm condition.

In ALF and ALR(A) this relay may be used as power failure warning.

See [“Fig. 4.7. Main Wiring Diagram.” on page 47](#), and [“Fig. 4.8. Input/Output Circuitry.” on page 48](#) and [“Fig. 4.11. Alarm interconnections” on page 52](#). The terminals have the following significance:

| Name | J100 pin no | Description |
|-------|-------------|--|
| ALCOM | 3 | Common terminal. |
| ALNO | 4 | Normally open contact. |
| ALNC | 5 | Normally closed contact (Normal = “No alarm” condition). |

External alarm reset function

- Can be connected at Keyb+/Keyb-, in parallel with external keyboard (if attached).
- External reset will disengage alarm relay and reset audio alarm (if enabled).
- Visual alarm (blinking digital depth indication on the right side of the screen) is not affected and must be reset locally by pressing any key on the panel.

External alarm reset terminals are as follows:

| Name | J100 pin no | Description |
|-------|-------------|---------------------------------------|
| KEYB+ | 10 | External alarm reset control input +. |
| KEYB- | 11 | External alarm reset control input -. |

Log Pulse input

See “[Fig. 4.7. Main Wiring Diagram.](#)” on page 47 and “[Fig. 4.8. Input/Output Circuitry.](#)” on page 48. Pulse input terminals are as follows:

| Name | J100 pin no | Description |
|-----------|-------------|--------------------|
| 100/200 + | 6 | Log pulse input +. |
| 100/200 - | 7 | Log pulse input -. |

If speed pulses are received on pin 6 -7 while VTG (Track and ground speed) values are received on the NMEA input, it is the pin 6 - 7 values that are shown as speed indication on top of the screen. If these pulses are removed, the NMEA value will be displayed instead.

Refer to “[Fig. 2.7. Screen 6, Interface setup screen.](#)” on page 19 for selection of the log pulse rate.

Remote Transducer Selector FEEDB (Feedback)

See “[Fig. 4.7. Main Wiring Diagram.](#)” on page 47 and “[Fig. 9.1 Transducer Selector Connection](#)” on page 66 and “[Fig. 9.2 Transducer Selector](#)” on page 67. Transducer selector control input terminals are as follows:

| Name | J100 pin no | Description |
|-----------|-------------|-----------------------------|
| STPRINT + | 8 | Transducer control input +. |
| STPRINT - | 9 | Transducer control input -. |

Transducer selector FORWARD position: (open - FORWARD/PORT transducer selected).

Transducer selector AFT position: (closed - AFT/STARBOARD transducer selected).

Transmitter trigger pulse and bottom pulse outputs

These outputs can be used to connect a repeater e.g. SKIPPER IR201, or to synchronize other hydroacoustic equipment to avoid interference. See “[Fig. 4.7. Main Wiring Diagram.](#)” on page 47 and “[Fig. 4.8. Input/Output Circuitry.](#)” on page 48. Pulse output terminals are as follows:

| Name | J100 pin no | Description |
|----------|-------------|--|
| XMIT E | 14 | Emitter of output opto coupler, transmitter trigger pulse. |
| XMIT C | 15 | Collector of output opto coupler, transmitter trigger pulse. |
| BOTTOM E | 16 | Emitter of output opto coupler, bottom pulse. |
| BOTTOM C | 17 | Collector of output opto coupler, bottom pulse. |

Analogue interfaces

GDS101 is equipped with analogue outputs to supply analogue repeaters or other equipment with analogue inputs. See “[Fig. 4.7. Main Wiring Diagram.](#)” on page 47. The signals are galvanically connected to the GDS101. See “[Fig. 4.8. Input/Output Circuitry.](#)” on page 48. Standard range is 0 - 10 V or 4 - 20 mA corresponding to shallow (UPPER) and deep (LOWER) settings. These settings may be accessed on “[Fig. 2.7. Screen 6, Interface setup screen.](#)” on page 19. Analogue outputs from the GDS101 have the following significance:

| Name | J100 pin no | Description |
|-----------|-------------|-----------------------------------|
| ANA 10 V | 20 | Positive analogue voltage output. |
| ANA REF | 21 | Negative analogue reference. |
| ANA 20 mA | 22 | Positive analogue current output. |
| ANA REF | 23 | Negative analogue reference. |




Fig. 4.10. Data Communication Interfaces.




Fig. 4.11. Alarm interconnections

External Interface Ports



Ground Stud. 5 x PG 13.5 cable entry 10-12 mm.

XJ303: NMEA ports D-type 9 pin female.

XCN6: VGA terminal HDD D-type 15 pin female.

XCN3: Printer port D-type 25 pin female.

Also, see [“Fig. 4.9. NMEA connector XJ303.” on page 49](#) and [“Fig. 4.10. Data Communication Interfaces.” on page 51.](#)

Fig. 4.12. External Interface Ports

Options

Repeaters/Slaves


Graphic CRT (VGA), LCD displays or digital depth slave repeaters may be connected to the system. Along with the graphic display repeaters, there may also be installed remote keyboard. The graphic repeaters require the installation of line driver units dependant on the distance between the main system and the repeater. See [“Fig. 4.7. Main Wiring Diagram.” on page 47](#) and [“Fig. 4.10. Data Communication Interfaces.” on page 51](#).

Remote Keyboard

The unit may optionally be operated from a remote keyboard/hand controller. See [“Fig. 4.7. Main Wiring Diagram.” on page 47](#)

| Name | J100 pin no | Description | Hand controller cable colour |
|-------------------|-------------|---------------------|------------------------------|
| KEYB+ | 10 | Keyboard signal. | Blue. |
| KEYB- | 11 | Keyboard reference. | Yellow and black. |
| INHIB+ (+12 V DC) | 12 | Keyboard power. | Red. |

Note: When connecting remote keyboard/hand controller, make sure jumper JP200 is present on the Power terminal board. This jumper provides +12 V DC to J100 pin 12 (INHIB+).



Remote Sounding Control.

This option lets the GDS101 being controlled remotely in synchronised (edge), burst (level) or single ping modes. If installed, these options are accessible on [“Fig. 2.4. Screen 3, 3rd Operation screen.” on page 16](#). Also see [“Fig. 4.7. Main Wiring Diagram.” on page 47](#) and [“Fig. 4.8. Input/Output Circuitry.” on page 48](#).

Sounder remote control terminals are as follows:

| Name | J100 pin no | Description |
|---------|-------------|-------------------------|
| INHIB + | 12 | Control Signal Input +. |
| INHIB - | 13 | Control Signal Input -. |

Refer to [“Fig. 2.7. Screen 6, Interface setup screen.” on page 19](#) for selection of the control signal polarity.

Note: With the present hardware, it is not possible, at the moment, to use “Remote Keyboard” and “Remote Sounding Control” (Navy option) simultaneously.

5. Start-up and system Adaption

System Adaptation

Analogue Output and Log Pulse Input Range Selection

From “[Fig. 2.7. Screen 6, Interface setup screen.](#)” on page 19 it is possible to set number of pulses per nautical mile (100, 200, 400 and 20000) for the log pulse input. Shallow (UPPER) and deep (LOWER) range limits for the analogue output may also be set, e.g.

- 50 m corresponding to 10 V or 20 mA.
- 0 m corresponding to 0 V or 4 mA.

Language and Units of Measure

From “[Fig. 2.6. Screen 5, Language and units of measure setup.](#)” on page 18 it is possible to select different languages and units of measure for the screen and printer character strings. The available languages are: English, French, Spanish, Russian, German and Norwegian.

Units of measure may be selected for:

| | |
|---------------|--|
| Depth | meters, feet, fathoms, braccias. |
| Picture speed | min:sec, (*nm/div, *km/div, *miles/div). *Only possible if an external speed log is connected. |
| Vessel speed | knots, km/h, miles/h. |
| Sound speed | m/s, feet/s |

Remote Transducer Selector

See “[Fig. 9.1 Transducer Selector Connection](#)” on page 66 and “[Fig. 9.2 Transducer Selector](#)” on page 67. Transducer selector control input terminals are as follows:

| Name | J100 pin no | Description |
|----------|-------------|-----------------------------|
| STPRINT+ | 8 | Transducer control input +. |
| STPRINT- | 9 | Transducer control input -. |

STPRINT-/STPRINT+ input is processed as transducer selector input (open - FORWARD/PORT transducer selected, closed - AFT/STARBOARD).

Low frequency indication

When the 38 kHz transceiver channel has been modified to a different frequency, is it possible from “[Fig. 2.6. Screen 5, Language and units of measure setup.](#)” on page 18 to adjust indicated value. Soft key SET LOW has five preset values (24/28/30/33/38 kHz) and encoder must be used to set any other value in the range of 10 - 250 kHz, when desired. Note that the 38 kHz channel must be activated first (see “[Fig. 2.3. Screen 2, 2nd Operation screen.](#)” on page 15, button “FREQUENCY”).

Note: After master reset procedure, the value is reset to factory default, and should be re-entered, if the actual value is different. For master reset, see “[Master Reset Procedure](#)” on page <?>.

NMEA Setup

“Screen 8” is used for verification of received and control of transmitted NMEA messages. See page 21. Two digital communication channels are provided:

- **COM 1** Primary NMEA 0183, (XJ303, RCV1 A/B-XMT1 A/B-XMT2 A/B).
- **COM 2** Secondary NMEA 0183/RS-232, (XJ303 NMEA: RCV2 A/B) and J302 (RS-232).

Each channel can be programmed individually with respect to the baud rate and scope of transmitted messages. Before configuration of the required channel, it must be selected by using the soft key IN/OUT. Primary channel is called COM 1, and secondary called COM 2. **Note:** Due to the present hardware configuration, the NMEA sentences selected for COM 1 will transmit from both XMT1 and XMT2. Settings set in COM 2 will only be present in the RS-232 output. The text window will represent information, which corresponds to the currently selected channel. The type of displayed messages received from external talker (if connected) or transmitted by the sounder, is selectable by using the soft key DISPLAY input/output. For more easy analysis of the window contents, display can be prevented from continuous update, if “DISPLAY off” is selected. The baud rate may be set to 4800 or 9600, 4800 being the more common. Transmitted messages are enabled individually by soft keys MESSAGE and STATUS. To enable/disable particular message, select it from the list by pressing MESSAGE button until required message appears on the same button and then select the status of this message (on/off) by pressing STATUS button. It is advisable at this stage to set display in “output” mode, to be able to observe current scope of transmitted messages. Transmitted talker identifier is SD, Sounder Depth.

NMEA transmitted/output messages

| | |
|---|---|
| Depth & Draught | \$SDDPT,xxxx.x,xxxx.x,xxxx.x*hh<CR><LF> |
| Depth below surface | \$SDDBS,xxxx.x,f,xxxx.x,M,xxx.x,F*hh<CR><LF> |
| Depth below transducer | \$SDDBT,xxxx.x,f,xxxx.x,M,xxx.x,F*hh<CR><LF> |
| Depth below keel | \$SDDBK,xxxx.x,f,xxxx.x,M,xxx.x,F*hh<CR><LF> |
| 1) Multiple transducer installation | \$PSKPDPT,x.x,x.x,x.x,xx,xx,c-c*hh<CR><LF> |
| Check sum on/off | CHECK SUM |
| Proprietary Skipper command for Kongsberg/Simrad EN250. Note: Normally not used on GDS101. | EN250 |
| Proprietary Skipper command for Kongsberg/Simrad EN250. Note: Normaly not used on GDS101. | EN250 D# |
| [Fore/Aft] transducer | \$SDXDR,D,x,x,M,c-c,<Cr><Lf> |
| ALR Set alarm state “Shallow alarm” | \$SDALR,134007.34,230,V,A,Shallow alarm*7B |
| ALF Alert sentence | \$SDALF,1,1,0,102103.00,A,A,V,,230,1,<1-99>,0,Shallow alarm,*hh |
| ALC Cyclic alert list. <every 30 sec. | \$SDALC,01,01,00,1,,230,,<1-99>*hh |

1) In case of multiple transducer installation, the following SKIPPER proprietary sentence must be selected:

| | |
|---|---|
| \$PSKPDPT,x.x,x.x,x.x,xx,xx,c--c*hh<CR><LF> | |
| | Check sum, possible to turn on/off (see screen 8) |
| | Transducer location * |
| | Echo sounder channel number (0-99)** |
| | Bottom echo strength (0,9) |
| | Maximum range scale in use, meters |
| | Offset from transducer, meters |
| | Water depth relative to transducer, meters |

* Text string, indicating transducer position: FWD/AFT/PORT/STB. If position is not preset by operator, empty field is provided.

** 1 = 38 kHz. =2 = 50 kHz. 3 = 200 kHz

NMEA received/input messages

The talker identifier is ignored:

Time

| | |
|------------------------|---------------------------|
| Universal Time | ZZU,xxxxxx |
| Universal Time & Local | ZLZ,xxxxxx,xxxxxx,-xx |
| Day, Month, Year | ZDA,xxxxxx,xx,xx,xxxx,-xx |

The time values will be indicated in the upper left corner of the screen, example: 11:43.

Position

| | |
|----------------------|----------------------------------|
| Geographical Lat/Lon | GLL,xxxx.xx,N,xxxx.xx,W |
| GPS Position | GGA,xxxxxx,xxxx.xx,N,xxxx.xx,W,x |

The position values will be indicated on top of the screen, right side, example: E059° 13.12' N010° 57.34'.

Alarm

| | |
|----------------------------------|--------------------------------------|
| Silence alarm for 30 seconds ALF | ACN,102104.00,,230,<1-999999>,s,c*hh |
| Request/Repeat ALF info ALF | ACN,102104.00,,230,<1-999999>,q,c*hh |
| Acknowledge alarm ALR(B). | ACK,xxx*hh<CR><LF> |
| Silence alarm ALR(A) | ACK,xxx*hh<CR><LF> |

Speed

| | |
|-------------------------|-------------------------------------|
| Dual ground/Water speed | VBW,uxx.xx,uxx.xx,a,uxx.xx,uxx.xx,a |
|-------------------------|-------------------------------------|

The speed value will be indicated on top of the screen, right side, example: 15.55 kts.

Composite

| | |
|-----------------------|---|
| GPS, Transit specific | RMC,xxxxxx,a,xxxx.xx,N,xxxx.xx,W,xx.x,xxx., xxxxxx.,*xx |
| Track & Ground speed | VTG,xxx.,T,xxx.,M,xx.x,N,xx.x,K |
| Heading & Water speed | VHW,xxx.,T,xxx.,M,xx.x,N,xx.x,K |

The composite values will be indicated on different positions on top of the screen, depending on message type.

The course over ground values from VTG will be indicated on top of the screen, right side, example: COG 123.0°.

Heading

| | |
|------------------------|------------|
| Heading, true, present | HDT,xxx.,T |
|------------------------|------------|

The heading value from HDT will have priority over VTG and be indicated on top of the screen, right side, example: HDT 123.0°. (Requires software version 5.06.08 or higher)

Simulation PSKP message

| | |
|----------------------------|--|
| Start/stop simulation mode | \$PSKPSIM,x.x*[CS][CR][LF] where x.x is a simulated depth value. |
|----------------------------|--|

The proprietary SKIPPER PSKP NMEA message is used to start and stop depth simulation mode. The message format is \$PSKPSIM,x.x*[CS][CR][LF], where x.x is a simulated depth value.

If the depth value is valid (0 - 1600 m), GDS101 will get into simulation mode, where this value is used for all indications and outputs (analogue, NMEA, bottom pulse). The “synthetic” bottom pulse which is generated can be observed on the echogram, “[Fig. 2.11. Screen 10, Oscilloscope screen.](#)” on page 23. The label “SIMUL” is blinking in the lower line - to indicate simulation mode. If the depth value is not valid (greater than the max range of 1600 m, or empty), the simulation mode will be turned off.

Setting of “Non-wheelmark” functions

Calibration, Sound Speed

The only calibration activity necessary is when the sound speed option is installed. In this case, set the required sound speed value in [“Fig. 2.4. Screen 3, 3rd Operation screen.” on page 16](#).

External Ping Control

When this option is installed, transmitter operation may be controlled by the external INHIBIT signal. The active polarity of this signal may be set on [“Fig. 2.7. Screen 6, Interface setup screen.” on page 19](#). The following function options are available on [“Fig. 2.4. Screen 3, 3rd Operation screen.” on page 16](#):

PING

| | |
|-------------------|---|
| Continuous | Transmitter operation is continuous and not affected by the external signal. |
| Edge | The transmitter is activated <u>once</u> by an active signal edge. |
| Level | The transmitter is controlled by the external signal level. An active level keeps the transmitter running, a passive level stops the transmitter. |
| Single | The transmitter is activated ping by ping by pressing the PICTURE SPEED button on the operator panel. The external INHIBIT signal is disabled. |

6. Specifications, Dimensions

| | | |
|---------------------------|---------------|--------------------------|
| Transducer, 38 kHz | Diameter. | 181 mm. |
| | Mounting. | Tank/sea valve/ice tank. |
| | Cable length. | 40 m. |
| | Weight. | ca. 20 kg. |
| | Protection. | IP 68. |

| | | |
|---------------------------|---------------|---|
| Transducer, 50 kHz | Diameter. | 90 mm. |
| | Mounting. | Tank/sea valve/ice tank/aluminium tank. |
| | Cable length. | 25 m or 40 m. |
| | Weight. | ca. 7 kg. |
| | Protection. | IP 68. |

| | | |
|----------------------------|---------------|----------------|
| Transducer, 200 kHz | Diameter. | 140 mm. |
| | Mounting. | Tank/ice tank. |
| | Cable length. | 25 m or 40 m. |
| | Weight. | ca. 8 kg. |
| | Protection. | IP 68. |

| | | |
|----------------------------|---------------|---|
| Transducer, 200 kHz | Diameter. | 90 mm. |
| | Mounting. | Tank/sea valve/ice tank/aluminium tank. |
| | Cable length. | 25 m. |
| | Weight. | ca. 7 kg. |
| | Protection. | IP 68. |

| | | |
|--------------------------------|--------------------|---------------|
| Transducer Junction Box | Size incl. glands. | 132 x 111 mm. |
| | Depth. | 55 mm. |
| | Weight. | 0.6 kg. |
| | Protection. | IP 56. |

| | | |
|------------------------------|----------------|------------|
| Operator unit cabinet | Height, front. | 340 mm. |
| | Width. | 320 mm. |
| | Depth. | 170 mm. |
| | Weight. | ca. 10 kg. |
| | Protection. | IP 42. |

Functional Properties

| | |
|---------------------------|---|
| Display. | 10,4" 158 x 211 mm graphic LCD screen with adjustable day/night vision and backlight. 640 x 480 pixels. |
| Printer. | HP Deskjet, Epson D88 or Epson LQ300. |
| Depth alarms. | Deep and shallow limits. |
| Calendar/Clock. | Year-month-day/hours-minutes-seconds (24 hour system). |
| Interface outputs. | Transmitter trigger pulse and bottom pulses. |
| | Analogue 4 - 20 mA and 0 - 10 V for depth. Detected video. |
| | IEC 61162-1:2007(E) (NMEA 0183) for alarm and depth. |
| | Alarm relay. |
| | Output for VGA repeater. |
| | RS-232 C. |
| | PC parallel printer port. |
| Interface inputs. | 100/200/400/20000 pulses for speed. |
| | IEC 61162-1:2007(E) (NMEA 0183) for speed, position, alarm, heading and time. |
| | Remote alarm reset. |
| | Remote transducer selector. |
| Languages. | English, French, Spanish, Russian, German and Norwegian. |
| Options. | VDR (Voyage Data Recorder) or IR301 digital remote depth indicator. |
| | LCD repeater. |
| | Remote keyboard. |
| | Remote sounding control. |
| | Autorange. |
| | Sound speed calibration. |

Performance

| | |
|-----------------------------------|------------------------|
| Depth range. | 1,5 m - 1600 m. |
| Graphic resolution. | 0.5 % of range. |
| Digital screen resolution. | <10 m: 0.01 m. |
| | >= 10 m <100 m: 0.1 m. |
| | >= 100 m: 1 m. |

| | | |
|-----------------------------------|------------------|----------------------------------|
| Transducer, 24 kHz/38 kHz. | Beam angle. | 16°/20° conical. |
| | Max. power. | 24 kHz = 1.5 kW/38 kHz = 1.0 kW. |
| | Effective range. | 3000 m/1500 m. |
| Transducer, 50 kHz. | Beam angle. | 33° conical. |
| | Max. power. | 1 kW. |
| | Effective range. | 750 m. |
| Transducer, 200 kHz. | Beam angle. | 6° conical. |
| | Max. power. | 1 kW. |
| | Effective range. | 350 m. |
| Transducer, 200 kHz. | Beam angle. | 10° conical. |
| | Max power. | 1 kW. |
| | Effective range. | 350 m. |

Environmental according to IEC60945:

Transducer and Junction Box

| | |
|----------------------------------|------------------------------|
| Operating temperature. | -15 - 55 degree C IEC 60945. |
| Storage temperature. | -20 - 70 degree C. |
| Protection, transducer. | 6 bar, IP 68. |
| Protection, junction box. | IP 56. |

Operator Unit Cabinet

| | |
|---|---|
| Supply voltage. | 230 V (195 - 253 V AC) or 115 V (96 - 125 V AC). |
| | 24 V DC (20 - 32 V). |
| Power consumption. | 50 W at 24 V, 70 W at 230 V AC or 115 V AC. |
| Alarm relay. | Change-over contact, max. 24 V 300 mA. |
| RS-232 C port. | Standard 25 pin D - type connector (located on terminal PCB inside cabinet). |
| NMEA port. | 9 pin D - type. 2 inputs, 2 outputs. |
| Operating temperature. | -15 - 55 degree C according to IEC60945. |
| | To increase serviceability and life-time, we suggest the working temperature to be held at 0 - 40 degree C. |
| Storage temperature. | -20 - 70 degree C. |
| Humidity. | 10 - 90 % relative, no condensation. |
| Protection. | IP 42. |
| Measuring accuracy 1,5 m - 10 m | Better than 0,1 m |
| Measuring accuracy 10 m - 1600 m | Better than 1 %. |

7. Service

- All service requests should be made to your local representative or to the manufacturer. (Contact information on title page).
- Adjustments and repairs should only be performed by qualified service engineers.
- Unqualified repair attempts will void the warranty.

CPU Board Setup Procedure

- Connect a PC keyboard and a VGA screen to the CPU board.
- Switch “On” the unit while pressing “Delete” key on the PC keyboard.
- Do not release the “Delete” key before the “Setup” picture is present on the screen.

CPU PCA 6742VE

(Bios version 1.12). The PCA 6742 has the default settings with the following changes. Start by loading the optimized defaults, and then change the following:

STANDARD CMOS FEATURES

Date: Change to todays date

Time: Change to time now

Halt on: No errors

Advanced BIOS Features

- a. Hard Disk priority [Press enter] – Press enter
 - i. 1 should be ch.1 M.
 - ii.2 should be ch 0 M.
- b. First Boot Device[Hard Disk]
- c. Second Boot Device [Hard Disk]
- d. Boot other device [Disabled]

Advanced Chipset features

- a. SMI712 VGA Settings [Press Enter] – Press enter
 - i. SMI712 VGA Monitor [Simul monitor]
 - ii. Panel resolution Mode [640x480 TFT]
- b. USB Device Setting [Press Enter] – press enter
 - i. USB1.0 emulation [Disabled]

Integral Peripherals

- a. Onboard serial Port 3 [enter]
 - i. Change to [2E8/IRQ9]
- b. Onboard serial Port 4 [enter]
 - i. Change to [3E8/IRQ5]
- c. Parallel Port Mode [EPP]
- d. EPP Mode Select [EPP1.9]

PnP/PCI Configurations

- a. Resources Controlled By [Manual]
- b. IRQ Resources [Enter]
 - i. IRQ – 7 assigned to [Legacy ISA]
 - ii. IRQ – 10 assigned to [Legacy ISA]
 - iii. IRQ – 11 assigned to [Legacy ISA]
- c. NO DMA

PC Health Status

- a. Case Open Warning [Disabled]

SAVE SETTINGS AND EXIT

Master Reset Procedure

After completed setup procedure, you should always do a ‘‘MASTER RESET’’:

- Switch off the GDS101, using the internal toggle switch and wait a few seconds.
- Then press down and keep pressed the soft key to the far right and far left (no. 1 and 6) in the upper row on the GDS101 keyboard.
- Turn the GDS101 ‘‘on’’ and keep the two soft keys pressed down until you hear 4 ‘‘beeps’’ and then release the keys.

Upgrading Software

New software versions are released from time to time. The GDS101 with Compact Flash (CF) can be updated by performing the following software upgrade procedure.


1. If you have received a programmed compact flash, skip stage 2.
2. Newest software may be downloaded from the web <http://www.skipper-service.no/skipdoc/skipdoc.php>. Under ‘‘software’’ you will find your equipment type. Also copy the latest version of startup.exe into the root folder.

Note: Standard Compact Flash reader is needed to be attached to the PC.

Note: It is possible to use the Compact Flash card, which is already installed in the display unit.

3. Switch Off the mains of the display unit and insert Compact Flash card with the new software on it.
4. Press the ‘‘hidden’’ button inside the cabinet (mounted on the solder side of the keyboard). Keeping the ‘‘hidden’’ button pressed, switch On the mains in the display unit and keep the button pressed until the message ‘‘You may release the upgrade button’’ appears in the lower part of the screen. If a new setup.exe is to be loaded, follow the on screen instructions.
5. Release the hidden button. After few diagnostic text messages, the list of available software versions will appear in the lower part of the screen as in example below.
6. Note: If the bootloader does not find any file with the software on the Compact Flash, the presently installed version will start automatically. In this case, make sure that the upgrade and setup file has been copied correctly on the Compact Flash and repeat the procedure.

| | |
|----------|----------|
| 05.06.01 | 05.05.17 |
| External | Active |



7. Select a software version, which you would like to install. Normally, it is possible to chose one out of two: 1) The version, which is currently installed in the internal memory (indicated as Active) and 2) the upgrade version (indicated as External). The version name is displayed in the upper line of the text lines, located just above the corresponding soft key. In the example above, soft key 1 should be pressed to select the latest software version.
8. Confirm selection by pressing YES button (or go back to selection, pressing NO).
9. Press any button to start the upgraded software (or it will start automatically in 5 seconds).
10. Note: The file with a previous software version will be copied back to the Compact Flash card, so it would be possible to re-install it in the similar manner, if desired.

Note: Always turn off the unit with the switch on the Terminal board when removing/replacing the CF disk.





8. Appendix, Miscellaneous Drawings

For repeater and repeater dimmer, see separate manual: IR301 manual

For tank and sea valve, see separate manuals:

| | |
|----------------------------|--|
| ETNSLJB-manual. | Single bottom sea valve (discontinued from 2007). |
| SB-100-manual. | Single bottom sea valve. |
| DB-100-manual. | Double bottom sea valve. |
| SB-200-manual. | For 24 and 38 kHz transducer deep sea. |
| Standard tank inst manual. | For 50 and 200 kHz transducer. |
| Combo tank inst manual. | For 24 and 38 kHz transducer deep sea. For different type of transducers, custom design is possible. |

All manuals (examples below) available on manufacturers homepage. (See title page for details).






Fig. 9.1 Transducer Selector Connection




Fig. 9.2 Transducer Selector




Fig. 9.3 Cable Gland Connection




Fig. 9.4 EMC Mounting Kit

9. Warranty and Utilization

Warranty:

- SKIPPER Electronics AS gives 12 months limited guarantee on all deliveries from SKIPPER Electronics AS, Norway.
- Please note that if the equipment is delivered by a third party, the third party's warranty conditions may apply.
- All warranty request should be sent to the local supplier of the equipment.

Utilization:

- This equipment is not to be disposed in normal waste, but be handled in accordance with applicable waste disposal regulations in the country where the equipment is used.