

## New Features

### 1.57

- Bug fixes to eliminate occasional crashing
- Improvements on web page for calibration and setup
- New bootloader version 0.53 made to eliminate occasional crashing
- Improvement in calibration pages
- Correction of calibration temperature compensating factors, this upgrade will require new calibration.
- Distance, trip and total and trip reset are now transferred to DL2 in DL21 configuration allowing DL1 data to be logged and transmitted from DL2 when DL2 is in SOG only mode.

### 1.58

- Bug fixes
- Compatibility issue with new hardware fixed

### 1.59

- New filter added to remove noise if on a single beam
- Alarms removed
- Web functions improved including run time screen
- Fix of test A – now passes in normal situations, even on large vessels
- Fix of AUX functions

### 1.60

- Bug fix of CN2 (present since 1.58)
- Diag Test A now shows '–' if sensor not working

### 1.61

- Another fix of CN2, now working in all setups
- Service password added to web page on master reset
- STW limit of -10kn removed